

Bluetooth Dongle

Bluetooth Adapter for 2 way radios



Adapter type Bluetooth dongle for connecting Bluetooth headset with 2 way radios.

Type: Bluetooth Adapter
 Operating Temp.: $-20^{\circ}\text{C}\pm 2^{\circ}\text{C} \sim 50^{\circ}\text{C}\pm 2^{\circ}\text{C}$
 Approx. Weight: 30g

BTD-2N2

Fully Qualified Bluetooth v2.1+EDR Chip set
 Chip Audio Line Input : 350mV rms (max.)
 Audio Output : 20 mV rms
 Transmitted Power : 1 dBm (typ.)
 Receiver Sensitivity : -82 dBm (typ.)
 One Key Definition
 PTT function built-in
 Power class 2,10 meters
 Display : One Color LED
 Support HSP, HFP,SPP.
 Power from radio 3.0V (special version)
 DC Current : 16 mA (avg.)

RECEIVER CONNECTORS AVAILABLE

MOTOROLA	GP-328	BTD-2M4	
KENWOOD	Multi-Pins	BTD-2K2	
ICOM	Multi-Pins	BTD-2S5	FCC:XTS-BTD-1M3
VERTEX	Multi-Pins	BTD-2Y5	CE:W6M21009-10911-E-16
AIRBUS TH9	Multi-pins	BTD-2N2	NCC:CCA111LP0600T1
EADS TH1N	Multi-pins	BTD-2N4	

HOW to Pair

Power OFF radio, plug dongle to radio.

Press PTT on dongle then power on radio for 3 seconds when LED is 2 flashes per second Release PTT then it's going to pairing mode.

NOTE: After paired every time when you attached the dongle then you need to reboot the radio to recognized the accessory. Or power on radio after the dongle plug in.

If you want to pair with BT-PTT or BT-PTT2.

Repeat above procedure , when 2 flashes LED press PTT again.

It's 3 flashes per second now, it's going to BT-PTT pairing mode.