

Blu-PTT Kodiak User manual (Android & iPhone)

1. Enter Pairing mode:

To enter pairing mode, turn on PTT, press PTT button for 10 seconds then release.


Stop all other APP's which could be occupied your PTT communication.

2. Change PTT pairing to a new phone:


1. In phone A, forget(un-pair) the PTT in "Setting" -> "Bluetooth"
2. Turn on PTT, make sure it is **NOT** connected to any phone.
3. Press PTT button for 10 seconds then release (like in 1).
4. Phone B now can scan the PTT button, pair and connect the PTT.

Part 1: Android phones: L4

1. Go phone's "Setting", turn on Bluetooth & Blu-PTT, wait for few seconds, "Blu-PTT" shows up in Bluetooth available device list




tap on it, Blue-PTT will connect to phone



Now Blu-PTT is connect to phone.

2. Run AT&T EPTT, in the main screen




tap “More”(the icon with three dots) on the bottom right, then “Setting” to open the setting menu:

Clear

Settings




in setting menu, in “Use Bluetooth” field, slide to “ON”



3. Back to main screen, pick an entry of the contact list, then use Blu-PTT to trigger PTT.


Part2 iPhone  L4

1. Go to “Setting”, turn on Bluetooth & Blu-PTT, wait for few seconds, “Blu-PTT” shows up in Bluetooth OTHER DEVICES list




Blu-PTT

tap on it, a message box pops up says Blu-PTT is requesting a pairing



tap on "Pair", Blu-PTT is now connected to your iPhone



2. Blu-PTT is ready use with your iPhone.