

# MP50B2

## Pairing Instruction

Pairing a new PTT-Z or Helmet Bluetooth :

1. Plug MP50B2 to the radio and power on the radio.
2. Pair with BT helmet ---->PRESS MP50B2 PTT then turn on the MP50B2 switch button (A) ON for 3 seconds.
3. The LED is blue flashes twice per second, it's going to BT helmet pairing mode.
4. Press your Bluetooth helmet power key (C) for 6-8s go into pairing mode.
5. It will paired automaticly.

1. Pair with PTT-Z ---->Press pairing key (B) for 3s and the green LED is 2 flashes every second
2. Open PTT-Z housing and slide it to power on. Press PTT-Z (Z) then the PTT-Z will be paired automaticly.



### How to use MP50B2

- Power on radio
- If you don't need to link Helmet bluetooth you can turn (A) to off and use the MP50B2 RSM and PTT-Z
- If you want to link to helmet bluetooth then (A) must be ON. After you remove the helmet and go away you need to turn (A) off.
- (A) is a switch between RSM speaker and Bluetooth helmet.
- (Z) is always ready for use with RSM or helmet.
- If you go to pairing mode all the paired list will be erased , you need to pairing again.