

iPSM-600 Zello User manual (Android & iPhone)

Part 1: Android phones:

1. Plug iSPM600 to your phone's 3.5mm ear-phone jack, two short "beep" sound indicates iSPM600 is powered on.
2. Before using iSPM600, make sure your phone's Bluetooth is turned off, go phone's "Setting", turn off the Bluetooth.
3. Run Zello, tap on "Menu" icon(three vertical dots) on the top right, then "Options" then "Push-to-talk buttons"




Options

Push-to-talk buttons

Configure, add and remove push-to-talk buttons

4. Press "+ ADD BUTTON" on the top right corner



Press the desired button now...


Press a Bluetooth, Bluetooth LE, headset or device button to add it to your PTT buttons list.

Cancel


- When "Press the desired button now.." message shows up, Press the "Answer" button(the orange color, round button below PTT button)




"Headset hook" is added to the PTT button list, now we need to set its action to toggle



press on "Headset hook" for few seconds until "Configure button" option shows up



press on "Configure button", in "Push-to-talk button action" drop-down list, choose "Toggle"



- Now iSPM600 is ready to use.

Part 2: iPhone:

1. Plug iSPM600 to your iPhone's 3.5mm ear-phone jack, two short "beep" sound indicates iSPM600 is powered on.
2. Run Zello, iPSM600 is ready to use, no setting needed.